Report Parameters:

EPSG Code: 26917

DEM File Name: Pineda Scalgo AggMedian16 NAD83

Units of DEM: Meters

DEM Aggregation Factor: 1

Clipped Flowlines Path: IRL-Pineda-Flowlines-Export NAD83.shp


Burn Width: 3


Burn Value: -2


Minimum Flow Accumulation - Channels: 1000 Minimum Total Pond Area per Microwatershed: 15

Max Number of Ponds per Microwatershed: 40


Digital Elevation Map - 1x1 - -2 depth, 6 wide Burn - EPSG:26917, Mete









D8 Channels - Min Flow Acc of 1000




## Microwatersheds - Delineated from Channel Junction Points



## Microwatersheds - Pond Overlay



Microwatersheds - Minimum Total Pond Area 15 Acres. Max Number of Ponds 40



## Microwatersheds Summary (20)

| Microwatershed_ID | Area_Acres | Pond_Count | Total_Pond_Area_Acres |
|-------------------|------------|------------|-----------------------|
| 3                 | 1511.45    | 24         | 105.83                |
| 10                | 1369.68    | 24         | 105.83                |
| 12                | 1081.41    | 17         | 88.50                 |
| 40                | 1751.45    | 24         | 62.15                 |
| 38                | 1597.16    | 22         | 57.97                 |
| 8                 | 506.89     | 7          | 47.08                 |
| 37                | 1279.41    | 15         | 42.12                 |
| 16                | 385.88     | 7          | 34.36                 |
| 33                | 1189.14    | 12         | 33.54                 |
| 22                | 585.08     | 10         | 30.22                 |
| 28                | 845.08     | 10         | 30.22                 |
| 25                | 762.59     | 10         | 30.22                 |
| 17                | 324.27     | 8          | 24.30                 |
| 35                | 459.45     | 11         | 24.20                 |
| 36                | 547.06     | 11         | 24.20                 |
| 29                | 261.01     | 9          | 21.87                 |
| 6                 | 417.07     | 6          | 18.17                 |
| 31                | 392.77     | 5          | 16.15                 |
| 20                | 476.09     | 6          | 15.16                 |