Report Parameters:

DEM File Name: Tomako FLA EPSG Code: 2881

Units of DEM: US Foot

DEM Aggregation Factor: 16

Clipped Flowlines Path: IRL-Flowlines-Export NAD83.shp


Burn Width: 4


Burn Value: -3


Minimum Flow Accumulation - Channels: 1000 Minimum Total Pond Area per Microwatershed: 20

Max Number of Ponds per Microwatershed: 50


Digital Elevation Map - 16x16 - -3 depth, 8 wide Burn - EPSG:2881, US Fo









D8 Channels - Min Flow Acc of 1000




Microwatersheds - Delineated from Channel Junction Points





Microwatersheds - Minimum Total Pond Area 20 Acres. Max Number of Ponds 50



Microwatersheds Summary (20)

| Microwatershed_ID | Area_Acres | Pond_Count | Total_Pond_Area_Acres |
|-------------------|------------|------------|-----------------------|
| 52 | 1948.11 | 44 | 131.59 |
| 18 | 4295.91 | 37 | 109.53 |
| 4 | 5122.23 | 44 | 100.88 |
| 9 | 4504.72 | 44 | 100.88 |
| 10 | 5012.18 | 44 | 100.88 |
| 17 | 4380.72 | 44 | 100.88 |
| 11 | 3464.95 | 41 | 94.18 |
| 58 | 1273.71 | 31 | 89.54 |
| 22 | 2889.06 | 38 | 88.39 |
| 38 | 1371.77 | 29 | 78.60 |
| 73 | 935.17 | 25 | 76.34 |
| 23 | 2592.96 | 29 | 70.95 |
| 37 | 850.30 | 25 | 68.28 |
| 29 | 2395.75 | 26 | 66.84 |
| 8 | 3070.22 | 18 | 61.70 |
| 35 | 2143.67 | 22 | 57.10 |
| 34 | 1924.90 | 21 | 56.09 |
| 40 | 1651.00 | 20 | 54.45 |
| 32 | 657.28 | 21 | 53.13 |
| 71 | 402.98 | 14 | 49.93 |